

6 720 648 053-00.2T

# Installation instructions

## Logano plus SB745

Output range 800 - 1200 kW

6 720 807 435 (2013/02) GB

Read carefully prior to installation and maintenance.

**Buderus**

## Table of contents

<b>1</b>	<b>Key to symbols and safety instructions</b>	<b>4</b>
1.1	Key to symbols	4
1.2	Safety regulations	4
<b>2</b>	<b>About the boiler</b>	<b>5</b>
2.1	Type overview	5
2.2	Correct use	5
2.3	Safety equipment	5
2.4	EU Declaration of Conformity	5
2.5	Scope of supply	5
2.5.1	Accessories supplied	5
2.5.2	Required accessories	5
2.6	Operating conditions	5
2.7	Suitable fuels	5
2.8	Data plate	6
2.9	Tools, materials and assembly aids	6
2.10	Product description	6
2.11	Dimensions and minimum clearances	8
2.11.1	Measurements	8
2.11.2	Unit data	9
2.11.3	Values for calculating the flue gas	10
2.11.4	Boiler parameters	10
<b>3</b>	<b>Information on installation and operation</b>	<b>11</b>
3.1	Standards, regulations and guidelines	11
3.2	Duty to obtain a permit and provide notification	11
3.3	Burner selection and settings	11
3.4	Installation requirements	12
3.5	Ventilation requirements	12
3.5.1	Open flue boilers	12
3.5.2	Room sealed boilers	12
3.6	Combustion air quality	12
3.7	Heating water quality	12
3.8	Using antifreeze	12
3.9	Electrical installation	12
3.10	Controller settings	12
3.11	Hydraulic connection to the heating system	14
3.12	Setting the minimum and maximum pressure limiters	14
3.13	Pressure maintenance	15
<b>4</b>	<b>Transport</b>	<b>15</b>
4.1	Moving the boiler with a forklift truck, pallet truck or heavy duty rollers	15
4.1.1	Lifting the boiler with a crane	16
4.1.2	Moving the boiler with a forklift truck	17
4.1.3	Moving the boiler with heavy duty rollers	17
4.1.4	Moving the boiler with pallet trucks	17
4.1.5	Removing the base frame	17

<b>5</b>	<b>Installation</b>	<b>18</b>
5.1	Siting the boiler	18
5.2	Fitting sound insulation strips	19
5.3	Levelling the boiler	19
5.4	Flue gas and water connections for heating system	19
5.4.1	General requirements of the flue system	19
5.4.2	Fitting a sealing collar (accessory)	20
5.4.3	Connecting the boiler to the pipework	20
5.4.4	Information on neutralisation	20
5.4.5	Filling the boiler and checking connections for leaks	21
5.5	Opening and reversing the combustion chamber door	21
5.5.1	Opening and closing the combustion chamber door	21
5.5.2	Refitting the door hinges	21
5.6	Fitting the burner (accessory)	22
5.6.1	Fitting the burner plate	22
5.6.2	Fitting the burner to the burner plate	23
5.7	Fitting and removing the front cover	24
5.8	Fitting the control unit (accessory)	24
5.8.1	Fitting the control unit support and cable conduit	24
5.8.2	Installing the control unit	24
5.8.3	Making the electrical connection	25
5.9	Fitting temperature sensors	26
5.10	Routing the burner cable	26
<b>6</b>	<b>Commissioning</b>	<b>27</b>
6.1	Flushing the heating system	27
6.2	Filling the heating system	27
6.3	Preparing the heating system for operation	28
6.4	Commissioning the control unit and burner	28
6.5	Setting control unit parameters	28
6.6	Commissioning report	29
<b>7</b>	<b>De-commissioning</b>	<b>30</b>
7.1	Shutting down the heating system	30
7.2	Shutting down the heating system in an emergency	30
<b>8</b>	<b>Inspection and service</b>	<b>30</b>
8.1	General notes	30
8.2	Preparing the boiler for inspection and maintenance	30
8.3	Cleaning the boiler	31
8.3.1	Preparing the boiler for cleaning with brushes	31
8.3.2	Cleaning the boiler with cleaning brushes	31
8.3.3	Cleaning the reversing chamber	31
8.3.4	Replacing the flue gas collector gasket	32
8.3.5	Fitting the covers to the flue gas collector and reversing chamber	32
8.3.6	Wet-cleaning the boiler	32
8.4	Checking and correcting the water pressure	33
8.4.1	When should you check the water pressure in the heating system?	33
8.4.2	Sealed unvented systems	33
8.4.3	Installations with automatic pressure maintaining systems	33
8.5	Inspection and service reports	34

<b>9</b>	<b>Remedying a burner fault .....</b>	<b>36</b>
<b>10</b>	<b>Environmental protection/disposal .....</b>	<b>36</b>
<b>11</b>	<b>System examples .....</b>	<b>36</b>
11.1	Layout of the minimum equipment for technical safety in accordance with EN 12828; operating temperature $\leq 105\text{ °C}$ ; cut-out temperature (STB) $\leq 110\text{ °C}$ .....	36
11.2	Safety equipment in accordance with the EC type inspection .....	37
11.3	Requirements for alternative items of safety equipment and other pieces of equipment .....	37
11.3.1	Safety valve requirements .....	37
11.3.2	High limit safety cut-out requirements .....	37
11.3.3	Maximum pressure limiter requirements .....	37
11.3.4	Minimum pressure limiter as low water indicator requirements .....	37
11.3.5	Water level limiter as low water indicator requirements .....	37
11.3.6	Burner requirements .....	37
11.3.7	Boiler controller .....	37
	<b>Keyword index .....</b>	<b>38</b>

## 1 Key to symbols and safety instructions

### 1.1 Key to symbols

#### Warnings



Warnings in this document are identified by a warning triangle printed against a grey background. Keywords at the start of a warning indicate the type and seriousness of the ensuing risk if measures to prevent the risk are not taken.

The following keywords are defined and can be used in this document:

- **NOTICE** indicates a situation that could result in damage to property or equipment.
- **CAUTION** indicates a situation that could result in minor to medium injury.
- **WARNING** indicates a situation that could result in severe injury or death.
- **DANGER** indicates a situation that will result in severe injury or death.

#### Important information



This symbol indicates important information where there is no risk to people or property.

#### Additional symbols

Symbol	Explanation
▶	Step in an action sequence
→	Cross-reference to another part of the document
•	List entry
–	List entry (second level)

Tab. 1

### 1.2 Safety regulations

#### Danger through failure to consider your own safety in an emergency such as a fire

- ▶ Never put your life at risk. Your own safety is paramount.

#### If you smell gas

- ▶ Close the gas isolator.
- ▶ Open the windows.
- ▶ Never operate electrical switches, including telephones, plugs or doorbells.
- ▶ Extinguish all naked flames.
- ▶ No open fire.
- ▶ Never smoke.
- ▶ Never use lighters.
- ▶ Warn all occupants in the building, but do not ring doorbells.
- ▶ Leave the building and telephone your national gas emergency service on 0800 111999 **from an outside phone**.

#### If you smell flue gas

- ▶ Switch off the appliance.
- ▶ Open windows and doors.
- ▶ Notify an authorised contractor.

#### Electric shock hazard

- ▶ Before carrying out any work on the heating system, disconnect the heating system from the power supply across all poles. For example, press the emergency stop switch outside the boiler room. It is not enough to switch OFF at the boiler control unit.
- ▶ Safeguard the heating system against unintentional reconnection.
- ▶ Observe the country-specific rules and regulations when making the electrical connection, commissioning, servicing and carrying out maintenance.

#### Installation and conversion

Insufficient ventilation can lead to dangerous flue gas leaks.

- ▶ Only have the boiler installed or modified by a competent person.
- ▶ Never modify any boiler components in contact with flue gas.
- ▶ With **open flue appliances**: Never cover or reduce the size of air vents in doors, windows or walls. If draught-proof windows are fitted, ensure there is an adequate ventilation.
- ▶ Ensure that the boiler installation room remains free from the risk of frost.
- ▶ The heating system must be installed and operated in accordance with the current: Statutory Instrument Laws, Gas Safety Regulations, IEE Regulations, Building Regulations, Local Water By-Laws, Health & Safety document 635 (The Electricity at Work Regulations) and any other local requirements. Observe all European and local installation standards, building regulations and the latest edition of the wiring regulations. Chemically aggressive substances, can corrode the appliance and invalidate any warranty.

#### Thermal disinfection

- ▶ **Risk of scalding!**  
Monitor any operation with temperatures in excess of 60 °C.

#### Inspection and service

- ▶ **Recommendation for customers:** Arrange a maintenance and service contract with the service department of the manufacturer or with an authorised contractor, covering an annual inspection and responsive maintenance.
- ▶ The user is responsible for the general and environmental safety of the heating system.
- ▶ Immediately correct all faults to prevent system damage!
- ▶ Use only genuine spare parts from the manufacturer. Losses caused by the use of spare parts and accessories not supplied by the manufacturer are excluded from the manufacturer's warranty.

#### Explosive and highly flammable material

- ▶ Never use or store highly flammable materials (paper, thinners, paints etc.) near the boiler.

#### Combustion/room air

- ▶ Keep the combustion/ambient air free of corrosive substances (e.g. halogenated hydrocarbons that contain chlorine or fluorine compounds). This will help prevent corrosion.
- ▶ Keep the combustion air supply free of dust.

#### Instructions to the customer

- ▶ Explain to the customer how the appliance works and how to operate it.
- ▶ Advise the customer that he/she must not make any modifications to the appliance or carry out any repairs on it.

#### Disposal

- ▶ Dispose of packaging in an environmentally responsible manner.

## 2 About the boiler

### 2.1 Type overview

Type	Output
SB745	800 kW, 1000 kW, 1200 kW

Tab. 2 Type overview

### 2.2 Correct use

The Logano plus SB745 condensing boiler has been designed for hot water heating systems in e.g. multiple dwelling units or for industrial purposes.

Any gas burner to EN 676 and EN 267 can be used if its operating range matches the boiler specification.

Only burners that have been tested and approved for electromagnetic compatibility (EMV/ENC) may be used. Logamatic 4000 control units are used with these boilers.

For further details on correct use → chapter 2.6, page 5, chapter 2.7, page 5 and chapter 3, page 11.

### 2.3 Safety equipment

To ensure safe operation, the boilers must be equipped with the following safety equipment:

- The level of safety equipment must comply with at least EN 12828.
- Also observe country-specific regulations if these specify further requirements.
- Observe the maximum temperature high limit stat setting of 110 °C.

Equipment examples are included in chapter 11, page 36. The components comprising the safety equipment are available as accessories.

### 2.4 EU Declaration of Conformity

The design and operation of this product conform to the applicable European directives and supplementary national requirements. Conformity has been demonstrated.

The Declaration of Conformity can be viewed at [www.buderus.co.uk](http://www.buderus.co.uk) or alternatively can be requested from your local Buderus sales office.

### 2.5 Scope of supply

The boiler is supplied with its full casing. The boiler front cover is supplied separately and has to be fitted.

- On delivery, check that all packaging is in perfect condition.
- Check the delivery for completeness.

The standard delivery consists of:

- Boiler body with casing
- Front cover

#### 2.5.1 Accessories supplied

The following accessories are included in the standard delivery and have to be fitted:

- Control unit retainer and cable conduit (delivered inside the combustion chamber)
- Sound insulation strips
- Siphon (delivered inside the combustion chamber)
- Insulating rings for blast tube (delivered inside the combustion chamber)
- Technical documentation

#### 2.5.2 Required accessories

The following accessories are not part of the standard delivery but are required to operate the boiler:

- Burner
- Burner plate, drilled or undrilled
- Boiler safety assembly
- Safety equipment
- Cleaning brushes
- Control unit

### 2.6 Operating conditions



During installation and operation of the heating system, observe all country-specific standards and guidelines. Also observe the details on the data plate. These are definitive and must be observed.



Set the burner to the combustion heating output QN specified on the data plate as a maximum.

Conditions of use	Unit	Value
Maximum permissible temperature for the high limit safety cut-out	°C	110
Maximum operating pressure	bar	6
Maximum number of burner starts	per annum	15 000

Tab. 3 Conditions of use

Operating conditions	Logano plus SB745	Logano plus SB745
Boiler water flow rate	None – in conjunction with a Logamatic control unit for modulating operation.	None – in conjunction with a Logamatic control unit 4212 for constant boiler water temperatures or when supplemented by a third party control unit.
Minimum boiler water temperature		
Interruption of boiler operation (total shutdown of boiler)		
Heating circuit control unit with heating mixing valve		
Minimum return temperature		
Miscellaneous	1)2)	1)

Tab. 4 Operating conditions

- 1) Maximum 15 000 burner starts per year. In order not to exceed the number of burner starts, observe the information on setting the control unit and burner in the technical guide or installation instructions. If this value is exceeded, however, please contact the manufacturer's service department.
- 2) The number of burner starts per year is affected by the boiler system's operating settings (controller parameters in the boiler controller and combustion setting) and sizing to correspond with the consumers' heat demand. To avoid exceeding the number of annual burner starts as a result of operating settings which have not been optimised, the manufacturer offers a complete commissioning and regular document inspections for floor standing residential conventional boilers, burners and boiler controller (Logamatic control units with function modules).

### 2.7 Suitable fuels



The combustion of biogas is not permitted.

#### Permissible fuels

- Natural gas from the public gas supply in accordance with national regulations with a total sulphur content < 50 mg/m<sup>3</sup>.

- LPG in accordance with national regulations with a content of elementary sulphur < 1.5 ppm and volatile sulphur < 50 ppm.

The boiler must only be operated with the specified fuels. Only burners that are suitable for the specified fuels may be used.

Observe the manufacturer's burner selection list and the burner manufacturer's instructions.

## 2.8 Data plate



If you contact the manufacturer with any questions about this product, always provide the details on the data plate. These details enable us to assist you specifically and quickly.

The data plate is fitted to the back of the boiler casing. There you will find information such as the serial number, output and approval details.

## 2.9 Tools, materials and assembly aids

For the installation and maintenance of the boiler, standard tools are required, as used for heating, gas, water and electrical installations, with the addition of a torque wrench.

## 2.10 Product description

The Logano plus SB745 is a floor standing condensing boiler with a slim, compact design and a small footprint, comprising a combustion chamber located at the top and a condensation heating surface located at the bottom. It is referred to below as the SB745 or the boiler.

The SB745 has two thermohydraulically separate return connections for the high and low temperature heating circuits.

For the type-tested boiler sizes with internal condensing heat exchanger and CE marking, the components that come into contact with products of combustion and condensate are made of stainless steel.

Equip the SB745 with a suitable burner.

Optional accessories can be found in the general catalogue.




**NOTICE:** System damage through the use of an incorrect burner.

- Only use burners that meet the technical requirements of the boiler (→ chapter 2.11, page 8).

The main SB745 components are (→ fig. 1):

- Boiler body [1] in conjunction with a burner  
The boiler block transfers the heat produced by the burner to the heating water.
- Thermally insulating casing  
The boiler jacket and thermal insulation reduce energy losses.
- Control unit [8] (accessory)  
The control unit monitors and controls all electrical boiler components.



6 720 648 053-13.2T

Fig. 1 Boiler overview

- [1] Boiler body
- [2] Combustion chamber door
- [3] Locking lug to secure the load during transportation  
(not for lifting the boiler)
- [4] Flue gas collector
- [5] Condensate drain, siphon
- [6] Drain
- [7] Base frame rail
- [8] Control unit (accessory)
- [9] Cable conduit
- [10] Flue gas connection
- [11] Inspection opening, reversing chamber
- [12] Return 1 (RK1), low temperature return (main return)
- [13] Return 2 (RK 2), high temperature return
- [14] Inspection opening on the water side (both sides)
- [15] Flow safety connection
- [16] Heating flow
- [17] Boiler safety assembly (accessories)
- [18] Lifting point

## 2.11 Dimensions and minimum clearances




Fig. 2 Boiler dimensions 800 kW, 1000 kW, 1200 kW

### 2.11.1 Measurements

	Abbreviation	Unit	Boiler type		
			800	1000	1200
Boiler size	—	kW	800	1000	1200
Length	L	mm	2545	2580	2580
	L <sub>K</sub>	mm	2360	2395	2395
Length incl. burner	L <sub>BR</sub>	mm	Subject to burner		
Width	B	mm	960	1040	1040
Width incl. control unit	B <sub>RG</sub>	mm	1220	1330	1330
Height	H <sub>K</sub>	mm	2014	2192	2192
Height of base frame <sup>1)</sup>	H <sub>GR</sub>	mm	140		
Installation clearance control unit, cable conduit	L <sub>RG</sub>	mm	906	906	906
Installation height, control unit	H <sub>RG</sub>	mm	1300	1300	1300
Transport length <sup>2)</sup>	—	mm	2405	2455	2455
Transport width	B	mm	960	1040	1040
Transport height <sup>1)</sup>	H <sub>EB</sub>	mm	1874	2052	2052
Installation area base frame	L <sub>GR</sub>	mm	2060		
	B <sub>GR</sub>	mm	960	1040	1040
Flue outlet	Ø D <sub>AAinternal</sub>	mm	253	303	303
	H <sub>AA</sub>	mm	1064	1193	1193
	A <sub>4</sub>	mm	299	348	348
Combustion chamber	Length	mm	1904	1954	1954
	Ø internal	mm	630	688	688
combustion chamber door	L <sub>BT</sub>	mm	227		
	H <sub>BT</sub>	mm	1508	1653	1653

Tab. 5 Boiler dimensions



	Abbreviation	Unit	Boiler type		
			800	1000	1200
Blast tube	Minimum depth	mm	210		
Boiler flow <sup>3)</sup>	Ø VK <sub>PN6</sub>	DN	100	125	125
	A <sub>2</sub>	mm	403	405	405
Boiler return flow 1 <sup>3)</sup>	Ø RK1 <sub>PN6</sub>	DN	100	125	125
	H <sub>RK1</sub>	mm	1007	1148	1148
	A <sub>5</sub>	mm	320	380	380
Boiler return flow <sup>3)</sup>	Ø RK2 <sub>PN6</sub>	DN	80	100	100
	H <sub>RK2</sub>	mm	300	263	263
	A <sub>6</sub>	mm	320	390	390
Safety valve/ Flow safety line <sup>3)</sup>	Ø VSL <sub>PN16</sub>	DN	65		
	A <sub>3</sub>	mm	400		
Boiler safety assembly connection	Ø AAB	"	G1		
	A <sub>1</sub>	mm	1200	1245	1245
Condensate outlet	Ø AKO	DN	40	40	40
	H <sub>AKO</sub>	mm	180	180	180
	A <sub>7</sub>	mm	71	70	70
Drain	Ø EL	"	R1		
	H <sub>EL</sub>	mm	161	164	164

Tab. 5 Boiler dimensions

- 1) The base frame rails can be temporarily removed to reduce the transport height.  
 2) after the dismantling of the combustion chamber door  
 3) Flange to EN 1092-1

### 2.11.2 Unit data

		Unit	Boiler type		
			800	1000	1200
Maximum flow temperature <sup>1)</sup>		°C	110		
Maximum operating pressure		bar	6		
Product ID no.			CE-0085 CM 0479		
Weight (empty)	Net	kg	1540	1792	1822
Operating weight <sup>2)</sup>	Gross	kg	2470	2992	3012
Water content		l	930	1200	1190
Hot gas volume		l	1020	1310	1320
Combustion heat output	Full load, max.	kW	742	928	1114
[Burner output Q <sub>n</sub> (Hi)]	Partial load 30 %	kW	223	278	334
Available draught		Pa	Subject to burner specification (50) <sup>3)</sup>		
Pressure drop on the hot gas side		mbar	6.4	6.5	7.5

Tab. 6 Unit data

- 1) Safety limit (high limit safety cut-out). Maximum possible flow temperature = safety limit (high limit safety cut-out) – 18 K.  
 Example: Safety limit (high limit safety cut-out) = 100 °C, max. possible flow temperature = 100 - 18 = 82 °C  
 2) Details excl. burner  
 3) Value in brackets is the recommended draught.

### 2.11.3 Values for calculating the flue gas

#### Values at system temperature 50/30 °C

		Unit	Boiler type		
			800	1000	1200
Rated output, natural gas	Full load	kW	800	1000	1200
	Partial load 30 %	kW	243	303	364
CO <sub>2</sub> content	Natural gas	%	10		
Flue gas temperature <sup>1)</sup>	Full load	°C	40		
	Partial load 30 %	°C	30		
Flue gas mass flow rate	Full load	kg/s	0.300	0.375	0.451
	Partial load 30 %	kg/s	0.089	0.112	0.134

Tab. 7 System temperature 50/30 °C

1) Calculated flue gas temperature for cross-sectional calculation to DIN EN 13384 (average value across the series). The actual flue gas temperature may differ from this, subject to burner setting and actual system temperature.

#### Values at system temperature 80/60 °C

		Unit	Boiler type		
			800	1000	1200
Rated output, natural gas	Full load	kW	725	906	1090
CO <sub>2</sub> content	Natural gas	%	10		
Flue gas temperature <sup>1)</sup>	Full load	°C	66	66	66
	Partial load 30 %	°C	36		
Flue gas mass flow rate	Full load	kg/s	0.316	0.395	0.475
	Partial load 30 %	kg/s	0.095	0.118	0.142

Tab. 8 System temperature 80/60 °C

1) Calculated flue gas temperature for cross-sectional calculation to EN 13384 (average value across the series). The actual flue gas temperature may differ from this, subject to burner setting and actual system temperature.

### 2.11.4 Boiler parameters

#### Pressure drop on the water side




Fig. 3 Pressure drop on the water side

[ $\Delta p_H$ ] Pressure drop on the heating water side

[ $\dot{V}_H$ ] Flow rate

[a] Logano plus SB745, boiler size 800

[b] Logano plus SB745, boiler size 1000/1200

#### Standby loss




Fig. 4 Standby loss subject to the average boiler temperature

[ $q_B$ ] Standby loss

[ $\phi_K$ ] Average boiler temperature

### 3 Information on installation and operation



Regarding installation and operation of your heating system, observe all relevant national standards and guidelines.

The information on the data plate is binding and must be observed.

#### 3.1 Standards, regulations and guidelines

Observe all technical guidelines, country-specific regulations and standards applicable to installation and operation. These include the following:

- Local building regulations concerning the installation conditions,
- Local building regulations concerning the ventilation and flue gas termination,
- Requirements for the electrical connection to the power supply,
- Technical rules of the gas supplier concerning the connection of a gas appliance to the public gas mains,
- Regulations and standards concerning the safety equipment level of water-filled heating systems  
The level of safety equipment must be at least compliant with EN 12828. Also observe country-specific regulations if these specify further requirements.

#### 3.2 Duty to obtain a permit and provide notification

- The local gas supplier might need to be notified of and approve the gas boiler installation
- Please note that regional approvals may be required for the flue system and condensate connection to the public sewage system
- Prior to commencing installation, inform the relevant bodies and the water board

#### 3.3 Burner selection and settings

The sizing and settings of the burner have a significant influence on the service life of the heating system. Every load cycle (burner on/off) causes thermal stresses (loads on the boiler body). **The number of burner starts must therefore not exceed 15,000 per year.**

The following recommendations and settings are designed to meet this criterion (**see also information on setting the control unit and the hydraulic connection to the heating system**). If you still cannot meet this criterion, please contact the sales or service department (the address can be found on the last page).



The number of burner starts can be checked in the MEC (→ chapter 3.10, page 12), on the third-party control unit or alternatively on the burner control unit.

- Set the burner output as low as possible. **Set the burner to the combustion heating output QN specified on the data plate as a maximum.** Never overload the boiler.




Fig. 5 Graph

- Take fluctuating net calorific values of the gas into account; check the maximum value with the gas supplier
- Only use burners that are suitable for the specified fuels. Observe the burner manufacturer's instructions.
- Burners must only be adjusted by qualified heating engineers!

### 3.4 Installation requirements

The installation room must meet the following conditions:

- In the boiler installation room, an ambient temperature of between 0 °C and 35 °C must be ensured.
- ▶ Never install system components that could be damaged by frost near the combustion air vents. If necessary, install a device to preheat the ventilation air (e.g. a heater bank in the combustion air vent).
- ▶ Never position objects in front of these vents. Keep the combustion air vents free at all times.
- ▶ Never store flammable materials or liquids in the immediate vicinity of the heat source.

### 3.5 Ventilation requirements

Ventilation for combustion and cooling should be provided in the boiler house in accordance with BS 6644 and IGE/UP/10. The tables below may be used for guidance.

#### 3.5.1 Open flue boilers

Opening free area sizes given in cm<sup>2</sup> per kW net.

% Load in Summer	Low level	High level
50	4	2
75	5	3
100	6	4

Tab. 9

#### 3.5.2 Room sealed boilers

Opening free area sizes given in cm<sup>2</sup> per kW net.

% Load in Summer	Low level	High level
50	2	2
75	5	5
100	6	6

Tab. 10

- ▶ Never restrict or block ventilation openings. Keep the ventilation openings clear at all times.

### 3.6 Combustion air quality

- ▶ Keep the supply of combustion air free of corrosive substances (e.g. halogenated hydrocarbons that contain chlorine or fluorine compounds). This will help prevent corrosion.
- ▶ Never use or store chlorinated cleaning agents or halogenated hydrocarbons (as contained in spray cans, solvents or cleaning agents, paints and adhesives, for example) in the boiler room.
- ▶ Keep the combustion air supply free of dust.
- ▶ If building work is taking place in the installation room and creating a lot of dust, shut the boiler down. A burner contaminated during building work must be cleaned before commissioning.

### 3.7 Heating water quality

The quality of the fill and top-up water is an essential factor for increased efficiency, functional reliability, long service life and for maintaining the constant operational condition of a heating system. If the system is filled with water that has a high calcium hardness, this will be deposited on the heat exchanger surfaces and will restrict the transfer of heat to the heating water. As a result, the wall temperatures of the stainless steel heat exchanger surfaces will rise and the thermal stresses (loads on the boiler body) will increase.

This is why the quality of the fill or top-up water must meet the conditions stipulated in the operator's log provided and be recorded in this log. The conditions for boilers > 600 kW require general water treatment

independent of the water hardness and the volume of fill and top-up water.

### 3.8 Using antifreeze



Chemical additives that are not certified as harmless by the manufacturer must not be used.

Antifreeze based on glycol has been used in heating systems for many years, for example Antifrogen N manufactured by Clariant.

The use of other types of antifreeze should not be a cause for concern if the product is comparable with Antifrogen N.

Observe the antifreeze manufacturer's instructions. Follow the manufacturer's details regarding mixing ratios.

The specific thermal capacity of Antifrogen N antifreeze is lower than the specific thermal capacity of water. To enable the transfer of the required heat output, increase the required flow rate accordingly. This should also be taken into account when sizing the system components (e.g. pumps) and the pipework.

As the heat transfer medium has a higher viscosity and density than water, take the higher pressure drop through the pipework and other system components into account.

Check the resistance of all plastic or non-metallic components in the system separately.

### 3.9 Electrical installation



**DANGER:** Risk to life and of system damage through faulty connections.

- ▶ Only carry out electrical work if you are a qualified electrician.
- ▶ Observe local installation regulations (→ chapter 3.1).
- ▶ The electrical installations must be suitable for damp areas.
- ▶ The system installer must issue a wiring diagram which records the interface between heating output elements, burner, control unit (Logamatic) and additional safety equipment.

#### 3.10 Controller settings



We recommend using a Buderus Logamatic control unit from the 4000 series.

The purpose of optimum control unit settings is to achieve long burner runtimes and avoid rapid temperature changes in the boiler. Gentle temperature changes result in a longer service life of the heating system. The control strategy of the control unit must therefore be prevented from becoming ineffective, i.e. through the boiler water controller switching the burner on and off.

- ▶ Maintain the minimum differential between the selected shutdown temperature of the high limit safety cut-out, the temperature controller, the maximum boiler water temperature and the maximum temperature demand (→ tab. 11).



The maximum boiler temperature can be selected on the control unit (MEC) in the "Boiler parameters" menu, under menu item "Max. shutdown temperature".

- ▶ Select set temperatures for the heating circuits that are as low as possible.

- Start heating circuits (e.g. when starting up in the mornings) in 5-minute intervals.



If a control unit from the Buderus Logamatic 4000 series is used, burner modulation in standard mode is not enabled for 3 minutes. Never modulate upwards more quickly than this.

Adjustable parameter (max. temperature)	Logamatic 4321	Logamatic 4211	
High limit safety cut-out (STB) <sup>1)</sup>	110 °C	110 °C	↑ Min. 18 K ↓
	↓↑ minimum 5 K ↓↑		
Temperature controller (TR) <sup>1)</sup>	105 °C	90 °C	
	↓↑ minimum 6 K ↓↑		
Max. boiler temperature	99 °C	84 °C	
	↓↑ minimum 7 K ↓↑		
Max. temperature demand <sup>2)</sup> of HC <sup>3)</sup> and DHW <sup>4)</sup>	92 °C	77 °C	

Tab. 11 Adjustable parameters Logamatic 4321 and Logamatic 4211

### Control unit settings




Fig. 6 Control unit settings

- [1] High limit safety cut-out  
[2] Temperature control unit  
[3] MEC

- Select temperatures (→ tab. 11, page 13) at high limit safety cut-out [1] in the control unit and at temperature controller [2].  
► Set the maximum boiler temperature on the MEC [3].



The maximum temperature demand is not a value that is directly selected. The maximum temperature demand is composed of the set temperature and the rise.

- 1) Set the high limit safety cut-out and temperature controller as high as possible, but ensure the settings are at least 5 K apart.
- 2) Both temperature demands must always be at least 7 K below the maximum boiler temperature.
- 3) The temperature demand of heating circuits equipped with a mixing valve is composed of the set flow temperature and parameter "Boiler rise" in the heating circuit data menu.
- 4) The temperature demand of DHW heating is composed of the set DHW temperature and parameter "Boiler rise" in the DHW menu.

### Settings for boiler water controller and maximum boiler water temperature

The boiler water controller is only designed to provide emergency operation with an adjustable boiler water temperature if the control electronics fail. In standard control mode, the function of the boiler water controller is provided by the maximum boiler water temperature. The maximum boiler temperature can be selected on the control unit in the "Boiler parameters" menu, under menu item "Max. shutdown temperature".

#### Example DHW demand:

Sum of the set DHW temperature (60 °C) and parameter **Boiler rise** (20 °C) in the "DHW" menu:

$$60\text{ °C} + 20\text{ °C} = \text{Maximum temperature demand } 80\text{ °C}$$

#### Example heating circuits:

Sum of the set temperature of the heating circuit with mixer with the highest temperature required (70 °C) and parameter **Boiler rise** (5 °C) in the "Heating circuit data" menu:

$$70\text{ °C} + 5\text{ °C} = \text{Maximum temperature demand } 75\text{ °C}$$



All maximum temperature demands must always be 7 K below the maximum selected boiler water temperature.

### Notes on setting third party control units



**NOTICE:** System damage if temperature sensor position is incorrect!

The temperature sensors of the high limit safety cut-out (STB) and of the temperature controller (TR) **must** be fitted at the installation location (→ fig. 26, [1], page 25) on the top of the boiler.

- ▶ In the case of third party control units, match the temperature sensor immersion sleeve to the diameter of the temperature sensors used.
- ▶ Do not change the length of the immersion sleeve.



Observe the operating conditions in chapter 2.6, page 5.

Observe chapter 5.9, page 26 when installing temperature sensors.

- The third party control unit (building management system or PLC controllers) must ensure a maximum internal boiler water temperature that is sufficiently different from the high limit safety cut-out. It must also be ensured that the control electronics rather than the boiler water controller switch the burner on and off.
- The control unit must ensure that the burner is switched to low load before being shut down. If this is not observed, the safety shut-off valve (SAV) in the gas train may lock out.
- Select control equipment that allows a gentle start-up with a time delay when the system is cold.
- After the burner demand, an automatic timer (for example) should limit the burner to low load for a period of approx. 180 seconds. A restricted heat demand will prevent uncontrolled cycling of the burner.
- It must be possible to show the number of burner starts on the control unit used.

	Unit	Value
<b>Temperature control unit</b>	<b>s</b>	40
<b>Monitor/limiter</b>	<b>s</b>	40
Minimum temperature difference between burner turning on and off	<b>K</b>	7

Tab. 12 Conditions of use

### 3.11 Hydraulic connection to the heating system

- ▶ If the system temperatures are different, use both return connectors RK1 (top) and RK2 (bottom).
- ▶ Connect heating circuits with high return temperatures to connector RK2, and heating circuits with low return temperatures to connector RK1.



For an optimum energy yield, we recommend supplying a flow rate of > 10 % of the total nominal flow rate via connector RK1, with a return temperature below the dew point.



Only return connector RK1 needs to be connected if only one return connection is used.

- ▶ Restrict the flow rate in the boiler to a maximum temperature difference of at least 7 K between flow and return.



Restriction of the temperature difference is not necessary if the system is equipped with a dirt separator.

- ▶ Size the pump correctly.



High flow rates and oversized pumps can result in the accumulation of sludge or deposits on the heat exchanger surfaces.

- ▶ Before connecting the boiler, flush sludge and dirt out of the heating system.
- ▶ Ensure that no oxygen enters the heating water during operation.
- ▶ We recommend to operate the boiler in sealed unvented systems wherever possible.

If the boiler is nonetheless used in an open vented heating system, additional measures are required to protect against corrosion and prevent sludge entering the boiler. Please note, the safety equipment required for boilers installed on open vented systems vary significantly from those on pressurised heating system.

- ▶ Consult the Buderus sales or service department for further advice.

#### Information on cascade circuits:

- ▶ Use the actual output the boilers have been commissioned to when sizing boiler primary pumps. The actual boiler output may vary from the maximum output of the appliance.
- ▶ Ensure identical temperature differences between flow and return on all boilers fitted in a cascade.

### 3.12 Setting the minimum and maximum pressure limiters

#### Maximum pressure limiter

The maximum pressure limiter (accessory) must be set in such a way that the safety valve is prevented from releasing excess pressure. To achieve this, the setting on the maximum pressure stat must be set to 0.5 bar below the discharge pressure of the safety valve. The maximum excess pressure of the safety valve for the SB745 is 6 bar.

#### Example:

Safety valve excess pressure:  $P_{SV} = 5 \text{ bar}$

Setting value, maximum pressure limiter:  $5 \text{ bar} - 0.5 \text{ bar} = 4.5 \text{ bar}$



The setting procedure for the maximum pressure limiter can be found in the documentation provided with the pressure limiter.

#### Minimum pressure limiter

The minimum pressure limiter (accessory) must be set in such a way that no steam bubbles form in the boiler, while still operating the boiler safely.

This setting depends on the system conditions and the siting of the boiler system. The set point is based on the boiling pressure corresponding the the maximum high limit stat setting (fixed at 0.5bar) and the static head to the highest point within the heating system.

#### Example:

Boiler system with high limit safety cut-out setting =  $110^\circ\text{C}$

Highest consumer above the boiler = 12 m  
(10 m equates to approx. 1 bar) → 1.2 bar

Safety margin = 0.2 bar (fixed value)

Response pressure  $P_{\min} = 0.5 \text{ bar} + 1.2 \text{ bar} + 0.2 \text{ bar} = 1.9 \text{ bar}$



The setting procedure for the minimum pressure limiter can be found in the documentation provided with the pressure limiter.

### 3.13 Pressure maintenance

- Size the expansion vessels correctly.
- Set the pre-charge pressures correctly.

If using pump-controlled pressure maintaining systems, pressure fluctuations will occur very frequently depending on the design of the system and the appliance settings. Even if these pressure fluctuations appear small, if they occur very frequently they may cause considerable damage to the boiler, as it is designed for a predominantly static pressure load.

To protection against damage:

- Ensure that every heat source is equipped with an individual expansion vessel.
- Set the pre-charge pressure of the expansion vessel correctly.

Recommended minimum volume of the expansion vessels if using pump-controlled pressure maintaining systems:

Floor standing condensing boiler	Capacity of expansion vessel in litres
Logano plus SB745-800	120
Logano plus SB745-1000	140
Logano plus SB745-1200	180

Tab. 13 Volume of expansion vessels

## 4 Transport



**DANGER:** Risk to life from inadequately secured boiler.

- Use suitable means to transport the boiler (e.g. several pallet trucks, a forklift truck, crane or heavy duty rollers).
- When transporting, secure the boiler to prevent it falling.

### Securing the load

To secure the load during transportation:

- **Never** pull retaining straps (fixing straps, chains) [2] over the boiler insulation [1].



The maximum tensile strength of each chain is 2 kN.

- **Only secure retaining straps to the locking lugs [1] (Fig. 7).**




Fig. 7 Securing the load

- [1] Locking lugs
- [2] Retaining straps (fixing straps, chains)
- [3] Boiler insulation

### 4.1 Moving the boiler with a forklift truck, pallet truck or heavy duty rollers



**DANGER:** Risk to life through falling load.

- Distribute the boiler weight evenly across the forklift truck/pallet truck when lifting and moving the boiler.
- Observe the weight of the boiler and that of the means of transport.
- When transporting, secure the boiler to prevent it falling.





**NOTICE:** System damage due to damaged boiler body. Only move the boiler with a forklift truck if the forks are long enough to reach right under the boiler.

- ▶ Prior to lifting the boiler, check that both lateral profiles of the boiler are supported by the forks of the forklift truck.
- ▶ Only lift the boiler at its profiles and base frame, not at the boiler body.
- ▶ Transport the boiler with the forks of the forklift truck inserted from the side.

The boiler can be transported by crane, forklift truck, several pallet trucks or rollers.

#### 4.1.1 Lifting the boiler with a crane



**DANGER:** Risk to life through falling load.

- ▶ Only use lifting ropes of the same length.
- ▶ Only use lifting ropes that are in perfect condition.
- ▶ Only hook lifting tackle into the lifting eyes provided in the gusset plates on top of the boiler.
- ▶ **Never hook lifting tackle into the locking lugs on the front and back of the boiler, or into the connectors.**
- ▶ Only lift the boiler with a crane if you are suitably qualified to operate the crane.
- ▶ Never lift the boiler with a crane on its side or on end.

- ▶ Insert the hooks of the lifting tackle into the eyes in both gusset plates (→ fig. 8, [2]) of the boiler body.



**Never use the locking lugs [3] for lifting.**

- ▶ Attach the crane hook to the lifting tackle (→ fig. 8, [1]).




Fig. 8 Lifting the boiler with a crane

- [1] Crane hook
- [2] Lifting eyes
- [3] Locking lugs (not suitable for lifting by crane)
- [4] Towing points for tow ropes
- [5] Contact points for lifting with a trolley jack
- [6] Base frame rail
- [7] Contact points for lifting with a forklift truck



### 4.1.2 Moving the boiler with a forklift truck

- Pass the forks of the forklift truck through both profiles of the base frame.
- Observe the dimensions of the transport apertures.




Fig. 9 Moving the boiler with a forklift truck

	Abbreviation	Dimensions in mm
Width	A	200
Clearance	B	700
Height	C	90

Tab. 14 Dimensions of the transport apertures

### 4.1.3 Moving the boiler with heavy duty rollers

- Position a heavy duty roller at each corner.

### 4.1.4 Moving the boiler with pallet trucks

- Push several pallet trucks under the base frame.
- Lift the boiler evenly with the pallet trucks.




Fig. 10 Moving the boiler with two pallet trucks



Note the position of the drain connector (→ fig. 1, [6], page 7) and condensate drain (→ fig. 1, [5], page 7).

### 4.1.5 Removing the base frame

The transport height can be reduced by removing the base frame rails (→ fig. 11, [1]) with the cross beams.

- Lift the complete boiler with a pallet truck (according to chapter 4.1.4, page 17) or from one side with a trolley jack (→ fig. 8, [5], page 16).
- Undo screws.
- Disassemble the base frame as shown in fig. 11.
- Drain the boiler.




Fig. 11 Removing the base frame

- [1] Base frame rails
- [2] Cross beam
- [3] Screw

- Install the base frame at the installation location by following this process in reverse.

## 5 Installation



For the installation and operation of the heating system, observe all country-specific standards and guidelines. The information on the data plate is binding and must be observed.

### 5.1 Siting the boiler



**DANGER:** Risk to life through poisoning!

Insufficient ventilation can lead to dangerous flue gas leaks!

- ▶ Never close off or reduce the size of ventilation and extract air vents.
- ▶ Never operate the boiler unless faults are rectified immediately.
- ▶ Inform the operator in writing of any faults and their associated risks.



**DANGER:** Risk of fire through flammable materials or liquids.

- ▶ Never store flammable materials or liquids in the immediate vicinity of the heat source.



**NOTICE:** System damage due to frost!

- ▶ Site the boiler in a room free from the risk of frost.



Observe local regulations and standards.

**Installation room requirements:**

- The support surface must provide sufficient load-bearing capacity and solidity.
- The installation room must be dry and free from the risk of frost.
- The size of the installation room must be adequate to ensure correct operation.

**Minimum wall clearances**

Observe the specified minimum wall clearances for the foundations or installation surface (→ tab. 15, page 18 and fig. 12, page 18). The surface on which the boiler is to be positioned must be of load-bearing capacity, even and level. The front edge of the boiler should be flush with the edge of the plinth.

The combustion chamber door can be fitted to open from right to left or vice-versa (→ chapter 5.5 from page 21).

For details on the boiler length L and boiler width B → chapter 2.11, page 8.



**Allow extra space if a flue silencer is to be installed.**



If separation between the installation site and the boiler is required to prevent the transfer of structure-borne noise, apply anti-vibration measures (e.g. anti-vibration supports) before installing the boiler.




Fig. 12 Installation room with boiler (with boiler door opening to the right)

Boiler size	800 kW	1000 kW	1200 kW
A <sub>H</sub> in mm <sup>1)</sup>	1000 (800)		
A <sub>V</sub> in mm <sup>2)3)</sup>	1800 (900)	1800 (1100)	
A <sub>S</sub> in mm	400 (50)		
L <sub>BR</sub> in mm	Burner length + 200 (800)		
L <sub>RG</sub> in mm	906		
Controller installation clearance			
Cable conduit			
Length (L) foundations	2300		
Width (B) foundations	1060	1140	

Tab. 15 Specified wall clearances (dimensions in brackets are minimum clearances)

1) If using a flue gas silencer, take its installed dimensions into account.

2) Factor in dimension L<sub>BR</sub> (burner length - available from burner manual) subject to burner overhang

3) This dimension depends on the burner length.

## 5.2 Fitting sound insulation strips



**DANGER:** Injury from crushing.



Consider additional sound insulation measures before installing the boiler.

To reduce the noise, place the sound insulation strips provided below the base frame, flush with the front and back of the boiler.

- ▶ Position the boiler at its installation site.
- ▶ Place sound insulation strips lengthways below the boiler frame at all four corners.
- ▶ Carefully set the boiler down.




Fig. 13 Positioning the sound insulation strips

[1] Sound insulation strips

## 5.3 Levelling the boiler

To prevent air collecting in the boiler, level the boiler horizontally and vertically



Use metal shims to level the boiler.

- ▶ Open the combustion chamber door (→ chapter 5.5.1, page 21).
- ▶ Place a spirit level on the combustion chamber floor.

- ▶ Level the boiler horizontally using the spirit level in the combustion chamber.




Fig. 14 Levelling the boiler

[1] Level

## 5.4 Flue gas and water connections for heating system

### 5.4.1 General requirements of the flue system



**DANGER:** Risk to life through poisoning!

Insufficient ventilation can lead to dangerous flue gas leaks!

- ▶ Never close off or reduce the size of ventilation and extract air vents.
- ▶ Never operate the boiler unless faults are rectified immediately.
- ▶ Inform the operator in writing of any faults and their associated risks.

Implementing the following recommendations concerning the installation of flue systems should guarantee trouble-free operation of the combustion system. Failure to observe these requirements can result in substantial operating problems during combustion and may even cause explosions.

These are frequently acoustic disturbances, compromised combustion stability or excessive vibrations on assemblies or their components. Low NO<sub>x</sub> combustion systems are to be viewed as being more sensitive to operating faults on account of their combustion control. Therefore, engineer and implement the flue system with particular care.

The flue system consists of a connection piece between the heat source and the vertical flue system itself (chimney).

When sizing and implementing the flue system, comply with the following requirements:

- Size flue systems in accordance with the respective national and local regulations and applicable standards.
- When selecting the material for the flue system, take into account the composition and temperatures of the flue gas to prevent damage and contamination of the system components that are in contact with flue gas.

- Only flue systems, which are approved for a flue gas temperature of at least 120 °C, may be used.
- Route the flue gas as directly as possible to the chimney considering the best possible flow characteristics (e.g. short, rising, and with the fewest possible bends). Provide a separate vertical flue for each boiler where possible. Take the thermal expansion of the system into account.
- Implement deviations in the connection pieces as favourably as possible where flow is concerned by using bends or deflectors. Connection pieces with several deviations should be avoided, as they would have a detrimental effect on air-borne and structure-borne noise as well as the start-up pressure hammer. Prevent sharp-edged joints between rectangular connection flanges and the connection pipe. As with any reductions/expansions that may be required, the angle of the joint should not exceed 30°.
- Where possible, connection pieces should be joined to the chimney to provide optimum flow characteristics and with an incline (at an angle less than 45°). Any terminal pieces at the chimney outlets must ensure the free discharge of flue gas to atmosphere.
- Any condensate must be able to drain freely over the entire length, be treated and drained off in accordance with local regulations.
- Provide inspection pieces in accordance with local regulations, if necessary after discussion with the local authorising body.
- The chimney must be separated from the boiler (e.g. with compensators) to prevent the transfer of structure-borne noise.
- If a flue gas damper is installed in the flue system, integrate an "OPEN" limit switch into the boiler control system for safety reasons. Combustion must only be able to start when the feedback from the limit switch confirms that the flue damper is fully open. A temperature drop inside the boiler is possible on account of the time it takes the actuator to move the damper into position. Set the "CLOSE" limit position at the flue gas damper in such a way that it never closes fully. This prevents damage to the fitted burner through heat build up.

#### 5.4.2 Fitting a sealing collar (accessory)

- Fit the sealing collar in accordance with the installation instructions supplied.

#### 5.4.3 Connecting the boiler to the pipework



**NOTICE:** System damage due to leaking connections!

- Connect pipes without stress to the boiler connections.



Boiler contamination on the water side is not permissible.

If required to prevent contamination, install a dirt separator in the boiler return.

#### Connecting the heating return

The boiler has two inlet options for the return water. If separate system returns for differing return temperatures are used (e.g. underfloor heating, DHW heating), these can be routed to the boiler via separate return connections.

- RK1 = Low return temperature (e.g. underfloor heating)
- RK2 = High return temperature (e.g. DHW heating)

On delivery, the return is sealed with a dummy flange. If using connection RK2:

- Remove dummy flange.

If there are no varying return temperatures, return connection RK1 is used.

- Connect the heating system return to the appropriate boiler return connection [5], [6].




Fig. 15 Boiler connections

- [1] Boiler safety assembly connection
- [2] Boiler flow connection
- [3] Safety valve/flow safety line (VSL) connections
- [4] Flue connection
- [5] Heating return connection 1 (RK1)
- [6] Heating return connection 2 (RK2)

#### Connecting the heating flow

- Connect the heating system flow to the boiler flow connection [2].

#### Connecting the boiler safety assembly

- Connect the fittings manifold (accessory) to the fittings manifold connection [1].

#### Connecting the safety valve



**NOTICE:** System damage through connecting the wrong assemblies to the safety flow connection.

- Never connect a DHW cylinder or other heating circuit to the flow safety connection.

- Connect the safety valve to the safety flow connection (VSL) (→ fig. 15, [3], page 20). In open-vented systems, the flow safety line is connected to the connection (VSL).

#### 5.4.4 Information on neutralisation



**NOTICE:** System damage through condensate.

- Always keep the condensate drain pipe working.
- Ensure that the condensate drain pipe and neutralising system are working.



For the installation and maintenance of the neutralising system, see the special installation instructions (included in the standard delivery of the neutralising system).



The condensate can run into the boiler through the flue pipe. If this is not possible, only use stainless steel or plastic tees in the separate hose inlet. With ceramic flue systems, fit a dirt separator (sludge trap).

- ▶ Push the siphon provided (condensate drain) onto the pipe connector (→ fig. 1, [5], page 7) on the flue gas collector.
- ▶ Tighten the union nut on the siphon.
- ▶ Connect the drain hose to the siphon connector using a hose clip.

#### 5.4.5 Filling the boiler and checking connections for leaks



**DANGER:** Injury and/or system damage through overpressure when conducting the tightness test. Pressure, control and safety equipment may be damaged through excessive pressure.

- ▶ When carrying out the tightness test, ensure that no pressure, control or safety equipment is fitted that cannot be isolated from the boiler water chamber.



The test pressure level is subject to the system components and the heating network. Observe country-specific regulations and standards.

Before commissioning, check the heating system for tightness to ensure that no leaks will occur during operation.

- ▶ Fill the heating system with water (→ chapter 6.1, page 27 and chapter 6.2, page 27).
- ▶ Check all connections for leaks.
- ▶ Pressure test the heating system.
- ▶ Check flange connection and boiler connections for leaks.
- ▶ Check the pipework for leaks.
- ▶ After the tightness test, reinstate all components that were taken out of operation. Ensure that all pressure, control and safety equipment is functioning correctly.

### 5.5 Opening and reversing the combustion chamber door



**WARNING:** Risk of injury through falling combustion chamber door.

- ▶ Never undo all four nuts on the combustion chamber door.
- ▶ Retighten the nuts that secure the combustion chamber door two weeks after commissioning.

As standard, the combustion chamber door pivots open from left to right.

The following instructions assume the standard pivoting direction.

The combustion chamber door can be converted to open to the left.

#### 5.5.1 Opening and closing the combustion chamber door

##### Opening the combustion chamber door

- ▶ Undo the four screws in the combustion chamber door.
- ▶ Pivot the combustion chamber door open.




Fig. 16 Opening the combustion chamber door

##### Closing the combustion chamber door

- ▶ Pivot the combustion chamber door closed.
- ▶ Fit the four screws in the combustion chamber with washers.
- ▶ Tighten the screws diagonally with a torque of 40 Nm.
- ▶ The complete gasket must be pressed centrally onto the middle. Check it has been fitted correctly by using chalk or a similar material to make a mark.

#### 5.5.2 Refitting the door hinges



**WARNING:** Risk of injury from falling parts.

While the door hinges are being refitted, there is a risk of the combustion chamber door falling.

- ▶ Refit the door hinges before mounting the burner.
- ▶ Ensure that the combustion chamber door is closed and secured with the four screws.

The combustion chamber door swings open as standard from left to right (right hinged).

The following instructions are based on the standard opening direction. If the available space requires it, the combustion chamber door can be converted to left hinged.

Before starting work:

- ▶ Have the washer from the folder of technical documents to hand.
- ▶ Open the combustion chamber door (→ chapter 5.5.1, page 21).
- ▶ When closing the combustion chamber door, insert the washer between the combustion chamber door and the lower l.h. door stay. Ensure that the hole for the hinge pin is in line with the hole in the washer.
- ▶ Close the combustion chamber door.
- ▶ Fit the four screws in the combustion chamber door.
- ▶ Tighten the compression spring with the Allen screw until the rocker arm to the hinge pin has some play (→ fig. 17, page 22).
- ▶ Remove retaining split pin [2] from hinge pin [1].




Fig. 17 Removing the retaining split pin

- [1] Hinge pin
- [2] Retaining split pin
- ▶ Pull the hinge pin (→ fig. 17, [1]) upwards out of the hinge.
- ▶ Unhook the rocker arm (→ fig. 18, [3], page 22).
- ▶ Release the compression spring (→ fig. 18, [1]) with Allen screw (→ fig. 18, [4]).
- ▶ Remove the compression spring.
- ▶ Fit the compression spring on the l.h. side.
- ▶ Fit the washer (→ fig. 18, [2]).
- ▶ Fit the Allen screw.
- ▶ Pre-tighten the Allen screw until the washer has a clearance of 60 mm towards the boiler front panel.
- ▶ Hook in the rocker arm.

- ▶ Pivot the rocker arm over the compression spring.




Fig. 18 Fitting

- [1] Spring
- [2] Washer
- [3] Rocker arm
- [4] Screw

- ▶ Slightly undo the screws for the door stays on the l.h. side until the door stays can be moved in the slot.
  - ▶ Push the hinge pin on the l.h. side from above through the hinge in the door stay and the door until it reaches the rocker arm.
  - ▶ Fit the retaining split pin through the hinge pin below the lower door stay (→ fig. 17).
  - ▶ Push the upper door stay on the l.h. side to the left and tighten the screws.
  - ▶ Push the lower door stay on the l.h. side to the right and tighten the screws.
- The hinge pin has no more play and the combustion chamber door will not drop when opened.
- ▶ Remove the four door screws.
  - ▶ Pivot the combustion chamber door open by 90°.
  - ▶ Release the compression spring with the Allen screw until the hinge pin lies in the lower door stay at the front of the slot.
- The combustion chamber door is hanging straight in the hinge.

## 5.6 Fitting the burner (accessory)



**NOTICE:** System damage through incorrect burner.

- ▶ Only use burners that meet the technical requirements of the Logano plus SB745 (→ chapter 2.11, page 8).

### 5.6.1 Fitting the burner plate



Predrilled and undrilled burner plates are available (accessories).  
The installation method depends on the particular burner used.

- ▶ Remove the protective plate from the combustion chamber door.



- Secure burner plate [3] with gasket [2] to combustion chamber door [1] using hexagon bolts and washers [4].




Fig. 19 Fitting the burner plate

- [1] combustion chamber door
- [2] Seal
- [3] Burner plate
- [4] Hexagon screws and washers

### 5.6.2 Fitting the burner to the burner plate



**DANGER:** Injury/system damage through excess loads.  
► Use suitable lifting gear for mounting the burner.



**WARNING:** Damage to health from inhaling fibre dust.  
Fibre dust may be inhaled when working on the thermal insulation.  
► Wear a breathing mask when working on the thermal insulation.



**NOTICE:** System damage through incorrect or missing insulating rings.  
► Only use the insulating rings supplied.



Refer to the installation instructions of the relevant burner for its mounting and connection.

As standard, the thermal insulation in the combustion chamber door has an aperture of 270 mm for the blast tube. If the blast tube is larger than this, the diameter of the aperture can be increased to a maximum of 360 mm.

If the hole in the thermal insulation of the combustion chamber door is increased, the insulating rings supplied will no longer fit (→ fig. 21, [4], page 23).

If the blast tube diameter is greater than 360 mm, consult your supplier. If the blast tube is not long enough to reach the inner edge of the thermal insulation, a 45° chamfer can be applied to the thermal insulation.

The combustion chamber door must be opened to allow the burner to be mounted.

- Open the combustion chamber door (→ chapter 5.5, page 21).
- Push a gasket (→ fig. 20, [1], page 23) onto the burner connector.




Fig. 20 Fitting the gasket

- [1] Seal
- Secure the burner to burner plate [2].
- Cut out insulating rings [4] in accordance with the diameter of blast tube [5].
- Fill the remaining gap on the inside of the combustion chamber door, between combustion chamber door insulation [3] and blast tube [5], with adapted insulating rings [4].




Fig. 21 Fitting the burner

- [1] Burner
- [2] Burner plate
- [3] Thermal insulation for combustion chamber door
- [4] Insulating rings
- [5] Blast tube



Omit the installation of the insulating rings if this is stated in the installation instructions from the burner manufacturer.

- Close the combustion chamber door and tighten the hexagon bolts (→ chapter 5.5, page 21).

### 5.7 Fitting and removing the front cover

- ▶ Hook lower front cover [3] into the holders on the right-hand and left-hand side of the boiler casing.
- ▶ Hook upper right front cover [2] into the holders on the boiler casing.
- ▶ Hook upper left front cover [1] into the holders on the boiler casing.




Fig. 22 Fitting the front cover

- [1] Upper l.h. front cover
- [2] Upper r.h. front cover
- [3] Lower front cover



To remove the front covers, proceed in reverse order.

### 5.8 Fitting the control unit (accessory)



We recommend fitting the control unit to the same side as the door hinges (factory-fitted on the right).

This chapter explains how to fit the Logamatic 4211, 4212, 4321 and 4322 control units and a temperature sensor set for the boiler.

The control unit can be fitted to a control unit support on the right hand or left hand side of the boiler. The control unit support is included in the standard delivery.

#### 5.8.1 Fitting the control unit support and cable conduit



Install separate cable holders for on-site cables.

- ▶ Mark the installation height of the control unit support (→ fig. 2, tab. 5, page 8).
- ▶ Trim and mark the cable conduit (→ fig. 2, page 8).
- ▶ Drill holes (Ø 5 mm).
- ▶ Secure the cable conduit with the self-tapping screws supplied.

- ▶ Secure the control unit support with the self-tapping screws supplied.




Fig. 23 Fitting the control unit

#### 5.8.2 Installing the control unit

Fig. 24 shows the control unit and the front cover [1] from the back.

- ▶ Undo the screws in the cover [1].
- ▶ Lift off the cover.
- ▶ Insert the control unit at the front with locking tabs [4] into the holes in the control unit support.
- ▶ Pull the control unit forwards and then tip backwards. Flexible hooks [2] must latch into openings [3].
- ▶ Secure the base of the control unit to the control unit support with two screws.




Fig. 24 Control unit



**Legend to fig. 24, page 24:**

- [1] Cover
- [2] Flexible hooks
- [3] Rectangular apertures in the control unit support
- [4] Locking tabs
- [5] Oval slots in the control unit support
- [6] Control unit
- [7] Holes for screws




Fig. 25 Installing the control unit

**5.8.3 Making the electrical connection****DANGER:** Danger to life through electric shock!

- ▶ Before opening the boiler, isolate the heating system across all poles and secure against unintentional reconnection.
- ▶ Carefully route the cables/leads and capillary tubes.
- ▶ Ensure that the capillaries are never kinked.
- ▶ Only carry out electrical work if you are a qualified electrician. If you are not suitably qualified, arrange for a qualified electrician to make the electrical connections.
- ▶ Observe local installation regulations.
- ▶ Create a permanent connection in accordance with EN 50165/EN 60 335-2-102 or the applicable international installation standards and local regulations.



The locations of terminal strips on different Logamatic control units are not identical. The terminal strip is easy to identify after the Logamatic control unit has been opened. The labelling of the terminal strip in the various control units is identical.

- ▶ Knock out or cut out the appropriate parts from the back panel (→ fig. 27, [1]) as required.
- ▶ Route all cables and leads for connecting the temperature sensors and safety equipment via the cable conduit to the back of the control unit.
- ▶ Route all on-site cables to the control unit.

- ▶ Route temperature sensor leads separately from other electrical cables.




Fig. 26 Cable conduit at the control unit

- [1] Temperature sensor immersion sleeve
- [2] Cable conduit
- [3] Control unit

- ▶ Make the plug-in connection in the control unit in accordance with the labelling on the terminal strip.
- ▶ Route the burner cable from below, behind the control unit support, to the control unit.
- ▶ Connect the burner cable to the control unit in accordance with the labelling on the plug-in connector strip.
- ▶ Secure the burner cable to the control unit support with the separate strain relief.
- ▶ Make on-site electrical connections to the appropriate plug-in connections according to the connection diagram (→ control unit documentation).




Fig. 27 Preparing the cable entry

- [1] Back panel section (Logamatic 4000)

Secure all cables with cable clips (part of the control unit standard delivery). Perform the following steps to secure the cables:

- ▶ Insert the cable clip together with the cable from the top into the slot in the frame.
- ▶ Slide the cable clip downwards.
- ▶ Counterhold.
- ▶ Flip the lever up.
- ▶ Fit the back panel.

- ▶ Refit the cover (→ fig. 24, page 24) to the control unit.
- ▶ Fix the control unit cover with the screws supplied (fig. 24, page 24).




Fig. 28 Securing a cable with a cable clip

### 5.9 Fitting temperature sensors



**NOTICE:** System damage through damaged capillaries or incorrectly fitted temperature sensor.

- ▶ Ensure that the capillaries are neither kinked nor squashed when uncoiling and routing them.
- ▶ Always push the temperature sensor right to the bottom of the sensor well.



**NOTICE:** System damage if temperature sensor position is incorrect!

The temperature sensors of the high limit safety cut-out (STB) and of the temperature controller (TR) **must** be fitted at the installation location (→ fig. 26, [1], page 25) on the top of the boiler.

- ▶ In the case of third party control units, match the temperature sensor immersion sleeve to the diameter of the temperature sensors used.
- ▶ Do not change the length of the immersion sleeve.



Standard immersion sleeve used: 3/4"

The boiler test point is at the top of the boiler shell (→ fig. 26, [1], page 25).

- ▶ Measure the depth of the sensor well.
- ▶ Mark the depth on the temperature sensor set (lead).
- ▶ **Insert temperature sensor set as far as it will go into the test point (to the bottom).**  
Use the mark to check whether the temperature sensors are correctly fitted.
- ▶ Secure the temperature sensor set in the test point with a sensor retainer.  
The plastic coil [2] for holding together the temperature sensor is pushed back automatically when it is inserted.



Insert compensating spring [1] between the temperature sensors to ensure a good contact between sensor well [4] and sensor surfaces, and thereby a reliable temperature transfer.




Fig. 29 Inserting the plastic coil into the sensor well

- [1] Compensating spring
- [2] Plastic spiral
- [3] Sensor retainer
- [4] Sensor well

- ▶ Never kink excess lengths of capillaries.
- ▶ Route the temperature sensor lead through the cable conduit to the control unit.
- ▶ Connect the temperature sensor lead to the control unit.

### 5.10 Routing the burner cable



Route the burner cable along the door hinge side (factory-fitted on the right).

- ▶ Route burner cable [4] from below, behind the control unit support, to the control unit (→ chapter 5.8.3, page 25).
- ▶ Connect burner cable [4] to control unit [3].
- ▶ Secure the burner cable with the external strain relief. Route the burner cable from the control unit to the burner.

- Connect burner cable [4] to the burner using the burner plug.




Fig. 30 Fitting the burner cable

- [1] Temperature sensor immersion sleeve
- [2] Cable conduit
- [3] Control unit
- [4] Strain relief
- [5] Burner cable

## 6 Commissioning



**NOTICE:** Risk of boiler damage through contaminated combustion air.

- Never operate the boiler in very dusty conditions, e.g. if building work is taking place in the installation room.
- Ensure adequate ventilation.
- Never use or store chlorinated cleaning agents or halogenated hydrocarbons (as contained in spray cans, solvents or cleaning agents, paints and adhesives, for example) in the boiler room.
- A burner contaminated during building work must be cleaned before commissioning.

- Complete the commissioning report (→ chapter 6.6, page 29).

### 6.1 Flushing the heating system



If the heating system contains several heating circuits, these must be flushed one after the other.

To prevent contamination in the boiler, flush the heating system prior to commissioning.

- Flush the system prior to connection to the boiler.

**-or-**

- Isolate the heating flow and return at the boiler.
- Connect the heating flow to a water connection.
- Connect hose to the heating return of the heating system.
- Route hose from the heating return to a drain.
- Open connected consumers (e.g. radiators).
- Flush the heating system with fresh water until clear water emerges from the heating return.
- Drain the heating system.

### 6.2 Filling the heating system



**NOTICE:** System damage due to temperature stresses!

- Only fill the heating system when cold (the flow temperature must not exceed 40 °C).
- During operation, only fill the heating system via the fill valve in the heating system pipework (return).



**CAUTION:** Health risk through contaminated drinking water.

- Observe all country-specific regulations and standards regarding the prevention of drinking water contamination. In Europe, observe standard EN 1717.



Open the automatic air vent valve only briefly for venting.

The fill and top-up water quality must comply with the specifications in the operator's log supplied.

The pH value of the heating water increases after the heating system has been filled. After 3 – 6 months (initial service) check whether the pH value of the heating water has settled down.

- ▶ Adjust the pre-charge pressure of the expansion vessel to the required pressure (only for sealed unvented systems).
- ▶ Open the mixing and shut-off valves on the heating water side.
- ▶ Fill the heating system slowly and observe the pressure gauge whilst doing so.
- ▶ Vent the heating system via the radiator air vent valves.

If the water pressure drops as a result of venting the system:

- ▶ Top up the system with water.
- ▶ Carry out a leak test in accordance with locally applicable regulations.
- ▶ After the tightness test, reinstate all components that were taken out of operation.
- ▶ Ensure that all pressure, control and safety equipment is functioning correctly.

Once the boiler has been tested for tightness and no leaks have been found:

- ▶ Set the correct operating pressure.
- ▶ Close the automatic air vent valve.

### 6.3 Preparing the heating system for operation



Concerning tightness on the flue gas side, a leakage rate of 2 % of the flue gas flow rate is permissible.

Observe the following points during commissioning:

- ▶ Before commissioning, vent the heating system via the ventilation facilities provided for this purpose.
- ▶ Check that the inspection aperture on the flue gas collector is closed.
- ▶ Check that the combustion chamber door is securely closed.
- ▶ Check that the safety equipment (e.g. safety valve, minimum and maximum pressure limiters, high limit safety cut-out) is functioning.

- ▶ Check that the required operating pressure has been built.
- ▶ Check the flange connections and other connections for tightness.
- ▶ Check the control unit connections and temperature sensor positions.
- ▶ Fill the condensate siphon.



According to standards, a leakage rate on the flue gas side of 2 % of the flue gas mass flow rate is permissible.

### 6.4 Commissioning the control unit and burner

By commissioning the control unit you automatically commission the burner as well. The burner can then be started by the control unit. For further information, see the installation instructions of the relevant control unit or burner.

- ▶ Use the control unit to commission the boiler.
- ▶ Set the control unit parameters (→ chapter 6.5, page 28).
- ▶ Complete the commissioning report in the technical documentation of the burner.

### 6.5 Setting control unit parameters

The controller settings listed in Tab. 15 apply to the Logamatic 4321 and 4322 control units.

For further information on setting the control unit, see chapter 3 from page 11.



To ensure that the Logamatic operates correctly if burner type "dual fuel burner" is selected, connect a floating contact to terminal "ES" to change the fuel type.

Burner		Control unit setting
Burner	Burner type for fuel Gas	Burner type to be selected
Single fuel burner	Modulating	Modulating
	2-stage	2-stage

Tab. 16 Controller settings for Logamatic 4321 and 4322 control units

## 6.6 Commissioning report

The boiler can be operated with an oil or gas burner.

► Sign all completed commissioning work and enter the date.

► Carefully complete the commissioning report for the relevant oil or gas burner.

	Commissioning steps	Page (individual steps)	Comments (signature)
1.	Flush the heating system.	Page 27	
2.	Fill the heating system with water.	Page 27	
3.	Vent the heating system.		
4.	Carry out tightness test.	Page 21	
5.	Switch on the control unit. ► Boiler-specific parameters set and recorded.	See technical documentation on the control unit as well as the specification, chapter 3.10, page 12 and chapter 6.5, page 28.	
6.	Ensure the function of all safety equipment.		
7.	Check the fuel line for tightness.		
8.	Starting the burner.	See technical burner documentation.	
9.	Complete the burner test report regarding the individual output stages.		
10.	Conduct a tightness test on the hot gas side. After a short time in operation, tighten the screws in the combustion chamber door to prevent leakage around the door as a result of the packing cord settling.		
11.	Check the flange connections and fitting after the boiler has been heated up and retighten.		
12.	Check flue path for tightness.		
13.	Check the flue gas temperature.		
14.	Carry out a function test on all safety equipment and record this.		
15.	Instruct the system user and hand over technical documentation.		
16.	Enter the fuel used in the table (→ "General" operating instructions).		
17.	Confirm professional commissioning.		
	Company stamp/signature/date		

Tab. 17 Commissioning report

## 7 De-commissioning



**NOTICE:** System damage due to frost.

When there is a frost, the heating system can freeze up if it is not operational, e.g. because of a fault shutdown.

- ▶ When there is a risk of frost, protect your heating system against freezing up.
- ▶ If your heating system has been shut down for several days due to a fault shutdown and there is a risk of frost, drain the heating water at the drain & fill valve. Also leave the air vent valve at the highest point in the system open.



**NOTICE:** System damage due to frost.

The heating system can freeze up as a result of a power failure or if the power has been switched off.

- ▶ Check the "Control unit settings" to ensure the system remains operational (especially when there is a risk of frost).

### 7.1 Shutting down the heating system

Shut down your heating system via the control unit. This also switches the burner off automatically.

- ▶ Set the On/Off switch of the control unit to "0" (Off).
- ▶ Isolate the fuel supply to the burner.

### 7.2 Shutting down the heating system in an emergency



Only in emergencies, switch OFF the heating system via the boiler room MCB/fuse or the heating system emergency stop switch.

- ▶ In dangerous situations, immediately close the main fuel shut-off valve and the power supply of the heating system via the boiler room main MCB/fuse or the heating system emergency stop switch.
- ▶ Isolate the fuel supply to the burner.
- ▶ Never put your life at risk. Your own safety is paramount.

## 8 Inspection and service

### 8.1 General notes



**NOTICE:** System damage due to inadequate cleaning and maintenance.

- ▶ Carry out cleaning and maintenance at least once a year. In the course of this work, check the entire heating system including the neutralising system for correct function.
- ▶ Immediately remedy all faults to prevent system damage.



Annual inspection and service are part of the warranty terms.



Use only genuine spare parts from the manufacturer. Spare parts can be ordered from the manufacturer's spare parts catalogue. The manufacturer address can be found on the last page.

Offer your customer an annual contract covering inspection and responsive service. For the work covered by such a contract, see chapter 8.5 "Inspection and maintenance reports", page 34.

### 8.2 Preparing the boiler for inspection and maintenance



**DANGER:** Risk to life from electric shock when the heating system is open.

- ▶ Prior to opening the heating system: Isolate the heating system from the mains power supply via the heating system emergency stop switch or the corresponding domestic MCB/fuse.
- ▶ Secure against unintentional reconnection.



**DANGER:** Risk to life through explosion of flammable gases!

- ▶ Work on gas components must only be carried out by qualified and authorised gas engineers.



If gas lines have to be detached from the gas burner, the combustion chamber door may only be opened by a qualified contractor.

- ▶ Shut down the heating system (→ chapter 7.1).

Prior to opening the combustion chamber door:

- ▶ Check the general condition of the heating system.
- ▶ Visual inspection and function check of the heating system.
- ▶ Check all system parts that carry fuel or water for leaks and visible corrosion.
- ▶ Open the combustion chamber door (→ chapter 5.5.1, page 23).

## 8.3 Cleaning the boiler

### 8.3.1 Preparing the boiler for cleaning with brushes



**CAUTION:** Risk of injury through falling parts.

- Prior to opening the doors, ensure that the hinge pin is correctly fitted in the combustion chamber door and secured with a spring washer.

- Remove the front cover (→ chapter 5.7, page 24).
- Remove the burner.
- Open the combustion chamber door (→ chapter 5.5, page 21).
- Clean the combustion chamber and the heating surfaces.
- Open the flue gas collector cover (→ chapter 8.3.5, page 32).
- Open the reversing chamber cover (→ chapter 8.3.5, page 32).
- Check the flue gas collector and condensate drain, and clean via the inspection aperture if required.

### 8.3.2 Cleaning the boiler with cleaning brushes



**WARNING:** System damage through using incorrect cleaning equipment.

- If cleaning with a brush, use only original cleaning brushes from the manufacturer.
- When cleaning only use brushes made of nylon or of stainless steel with a stainless steel linkage.

- Clean the heating surfaces of the combustion chamber (→ fig. 31, [1]) with the cleaning brush [2].
- Remove any cleaning residues with a vacuum cleaner.
- Check the seals around the boiler door, reversing chamber and flue gas collector, and replace if required.
- Close and secure the combustion chamber door.




Fig. 31 Cleaning the heating surfaces

- [1] Combustion chamber (heating surfaces of combustion chamber)
- [2] Cleaning brush

### 8.3.3 Cleaning the reversing chamber



Remove casing sections from the boiler as the cleaning cover is located underneath.



If you do not push the whole bristle part of the cleaning brush right through the secondary heating pipe, you will find it very difficult to remove the brush from the pipe.

- Push the bristle part of the cleaning brush right through the secondary heating pipe until the bristles emerge at the other end of the pipe.

To be able to remove combustion residues from the reversing chamber, remove the reversing chamber cover. This is located at the back of the boiler.

- Remove the casing and insulation.
- Undo the nuts and washers in the reversing chamber cover.
- Remove the reversing chamber cover.




Fig. 32 Removing the reversing chamber cover

[1] Reversing chamber cover

- Undo the nuts and washers in the flue gas collector cover.
- Removing the cover.
- Clean the secondary heating pipes with a brush (→ fig. 33, page 32).



- Remove all loose combustion residues from the combustion chamber (→ fig. 31, [1], page 31), the hot gas flues and the reversing chamber (→ Fig. 32, [1]).




Fig. 33 Cleaning the flue gas collector

[1] Cleaning brush

#### 8.3.4 Replacing the flue gas collector gasket



Replace the gasket in the flue gas collector cover during the annual service.

- Remove the old gasket and adhesive residues.
- Trim the new gasket.
- Affix the new gasket directly to the edge of the flue gas collector.
- Allow abutting edges to overlap.
- Cut off abutting edges at an angle of 45°.
- Press diagonally abutting edges together leaving no gap.

#### 8.3.5 Fitting the covers to the flue gas collector and reversing chamber



**DANGER:** Risk of poisoning through escaping gases. Flue gas can escape during operation if the flue gas collector and condensate drain pipe are not correctly sealed.

- Carefully seal the flue gas collector with its inspection cover and the condensate drain pipe with the siphon and hydraulic seal.

- Check the reversing chamber gasket for damage and replace if required.
- Position the flue gas collector cover.
- Tighten the nuts with a torque of 15 Nm.
- Position the reversing chamber cover and secure tightly.
- Secure lagging mat.
- Mount the burner.
- Mount the front cover.
- Restart the heating system.

#### 8.3.6 Wet-cleaning the boiler



**NOTICE:** System damage through moisture in the control unit. If moisture enters the control unit, it will be damaged. Never allow any spray to enter the control unit.

- Ensure that you only spray cleaning agent onto the heating surfaces of the hot gas flues and the combustion chamber.



**NOTICE:** System damage through cleaning agents in connected components.

If liquids displaced by the cleaning agents are channelled through connected components, e.g. siphon, neutralising system etc., these components may become inoperable or be damaged.

- Protect or remove connected components.



For wet cleaning (chemical cleaning), observe the operating instructions and safety instructions of the cleaning equipment and cleaning agent.

For wet cleaning, ensure that the cleaning agent is chloride-free.

- Observe the cleaning agent safety instructions.

When wet-cleaning, use a cleaning agent appropriate for the level of contamination.

For wet cleaning, proceed according to the manufacturer's instructions.

Liquid cleaning residues can be drained off through the condensate drain pipe on the flue gas collector.

- Disconnect the heating system from the power supply.
- Close the fuel supply. Disconnect the neutralising system and siphon prior to wet cleaning.
- Cover the control panel with foil to prevent spray from entering it.



- Clean the boiler according to the instructions of the cleaning equipment manufacturer.




Fig. 34 Opening/closing the cleaning drain

- [1] Dummy cap for cleaning drain
- [2] Cleaning drain

After cleaning:

- Reconnect the condensate drain pipe.
- Reconnect the condensate connection.
- Check the seals around the combustion chamber door and flue gas collector, and replace if required (→ chapter 8.3.4 and chapter 8.3.5, page 32).
- Close and secure the combustion chamber door.
- Close and tightly seal the flue gas collector (→ chapter 8.3.4 and chapter 8.3.5, page 32).
- Continue to ensure adequate ventilation of the boiler room.
- Remove the foil from the control unit.
- Restart the heating system.

## 8.4 Checking and correcting the water pressure

The heating system must contain sufficient water to ensure its correct function.

- If the water pressure in the heating system is too low, top up with water.
- Check the water pressure monthly.

### 8.4.1 When should you check the water pressure in the heating system?



The fill and top-up water quality must comply with the specifications in the operator's log supplied.



Air pockets may form in the heating system through the fill or top-up water releasing gases.

- Vent the heating system (e.g. bleeding the radiators).
- If required, top up with water.

Recently added fill or top-up water loses much of its volume in the first few days because it releases gases. With new systems you should therefore initially check the heating water pressure on a daily basis, and then at gradually longer intervals.

- Once the heating system is hardly losing any volume, check the heating water pressure monthly.

A distinction is generally made between open vented and sealed unvented systems. In practice, open vented systems are seldom

installed nowadays. We will therefore be using a sealed unvented heating system to demonstrate how you can check the water pressure. All settings will have already been made by the contractor when the system was first commissioned.

### 8.4.2 Sealed unvented systems



**NOTICE:** System damage due to frequent topping up! Subject to the water quality, your heating system can be damaged through corrosion or scaling.

- Ensure that the heating system is vented correctly.
- Check the heating system for leaks and the expansion vessel for functionality.
- Observe the requirements regarding water quality (see operator's log).
- If water loss occurs frequently, locate the cause and rectify the problem without delay.



**NOTICE:** System damage due to temperature stresses!

- Only fill the heating system when cold (the flow temperature must not exceed 40 °C).
- During operation, only fill the heating system via the fill valve in the heating system pipework (return).

For sealed unvented systems, the pressure gauge needle [3] must be within the green band [2]. The red needle [1] of the pressure gauge must be set to the pressure required for the heating system.

- Checking the heating system water pressure.
- Top up the heating water if the pressure gauge needle [3] drops below the green band [2].
- Top up with water via the filling valve in the heating system pipework.
- Vent the heating system.
- Check the water pressure once more




Fig. 35 Pressure gauge for sealed unvented heating systems

- [1] Red needle
- [2] Green marking
- [3] Manometer needle

### 8.4.3 Installations with automatic pressure maintaining systems

For installations in which an automatic pressure maintaining system is integrated, observe the manufacturer's instructions.

The water quality requirements also apply here (→ chapter 8.4.1, page 33).

## 8.5 Inspection and service reports

The inspection and maintenance reports provide an overview of the required inspection and service steps that should be carried out annually.

Complete these reports after inspections and service. The report can also be used as copying template.

► Sign and date the completed inspection work.



Warranty:  
Annual inspection and service are part of the warranty terms.

	Inspection work	Page (individual steps)	Notes
1.	Check the general condition of the heating system (visual inspection).		
2.	Check the heating system function.		
3.	Check the components in contact with fuel and water throughout the system for the following: <ul style="list-style-type: none"> <li>• Tightness</li> <li>• visible signs of corrosion</li> <li>• Signs of ageing</li> </ul>		
4.	Check the combustion chamber and heating surface for contamination and clean them. For this, shut down the heating system.	Page 31	
5.	Check gaskets/packing cords on combustion chamber door and replace if required.		
6.	Check and clean the burner. <ul style="list-style-type: none"> <li>► Visual inspection and remove any contamination.</li> <li>► Check all safety equipment (safety shutdown).</li> <li>► Function check</li> <li>► Flue gas analysis with test report for each output stage.</li> </ul>	See technical burner documentation.	
7.	Check the flue for function and safety.	See technical burner documentation.	
8.	Check the hydraulic seal of the condensate siphon and supplement if required.		
9.	Check the water pressure and pre-charge pressure of the expansion vessel.	Page 33	
10.	If necessary, check the operation of the DHW cylinder and the magnesium anode.	See technical DHW cylinder documentation.	
11.	Check the control unit settings are suitable and adjust if required.	See technical control unit documentation.	
12.	Test all safety equipment (safety shutdown) and record findings. For example: <ul style="list-style-type: none"> <li>► High limit safety cut-out</li> <li>► Pressure limiter min.</li> <li>► Pressure limiter max. (if installed)</li> <li>► Other safety equipment.</li> </ul>		
13.	Conduct a water analysis and record the results in the operator's log: <ul style="list-style-type: none"> <li>► pH value</li> <li>► Residual hardness</li> <li>► Oxygen binder</li> <li>► Phosphate</li> <li>► Electrical conductivity</li> <li>► Appearance</li> <li>► Check water records (e.g. amount of top-up water) in the operator's log.</li> </ul>		
14.	Check the neutralising system.		
15.	Final check of the inspection work, take measurements and record values and test results.		

Tab. 18 Inspection report

	<b>Inspection work</b>	<b>Page (individual steps)</b>	<b>Notes</b>
16.	Confirm professional commissioning.  Company stamp/signature/date		

Tab. 18 Inspection report

	<b>Demand-dependent maintenance</b>	<b>Page (individual steps)</b>	<b>Notes</b>
1.	Shutting down the heating system.	Page 30	
2.	Clean the combustion chamber.	Page 31	
3.	Clean the hot gas flues (heating surfaces)	Page 31	
4.	Check gaskets/packing cords on the combustion chamber door, inspection apertures in the reversing chamber and flue gas collector, and replace if required.		
5.	Check that the condensate drain pipe is clean and filled with a hydraulic seal.		
6.	Check the neutralising system.	See technical documentation of the neutralising system	
7.	Start up the heating system.	Page 27	
8.	Final check of the maintenance work, take measurements and record values and test results.	See technical burner documentation.	
9.	Check the function and operational safety (safety equipment).		
10.	Confirm professional commissioning.  Company stamp/signature/date		

Tab. 19 Heating system maintenance report

## 9 Remedying a burner fault


**NOTICE:** System damage due to frost.

When there is a frost, the heating system can freeze up if it is not operational, e.g. because of a fault shutdown.

- If your heating system has been shut down for several days due to a fault shutdown and there is a risk of frost, drain the heating water at the drain & fill valve. For this, the automatic air vent valve at the highest point in the heating system must also be open.


**NOTICE:** System damage from pressing the reset button too frequently.

This can damage the burner ignition transformer.

- Press the reset button no more than three times in a row.

The display shows heating system faults. Further information on the fault displays can be found in the service instructions of the relevant control unit. In addition, burner faults are signalled by an indicator on the burner.

- Press burner reset button (see burner operating instructions).

If the burner still fails to start after three attempts, contact a qualified heating engineer.

## 10 Environmental protection/disposal

Environmental protection is a key commitment of the Bosch Group. Quality of products, efficiency and environmental protection are equally important objectives for us. All legislation pertaining to the environment is strictly observed. To protect the environment we use the best possible technology and materials, subject to economic considerations.

### Packaging

Where packaging is concerned, we participate in country-specific recycling processes that ensure optimum recycling. All of our packaging materials are environmentally compatible and can be recycled.

### Obsolete equipment

Old appliances contain materials that should be recycled. The relevant assemblies are easy to separate, and all plastics are identified. In this manner the individual components are easily sorted and added into the recycling and disposal systems.

## 11 System examples

### 11.1 Layout of the minimum equipment for technical safety in accordance with EN 12828; operating temperature $\leq 105^\circ\text{C}$ ; cut-out temperature (STB) $\leq 110^\circ\text{C}$

The schematic representation shows the minimum equipment for technical safety in accordance with EN 12828 for the system versions designated here - without claim of completeness.

Practical implementation is subject to current technical rules.

Boilers  $> 300\text{ kW}$ ; operating temperature  $\leq 105^\circ\text{C}$ ; shutdown temperature (STB)  $\leq 110^\circ\text{C}$




Fig. 36 Safety equipment to EN 12828 for boilers  $> 300\text{ kW}$  with high limit safety cut-out  $\leq 110^\circ\text{C}$  (direct heating)

- [RK] Return
- [VK] Heating flow
- [1] Heat emitters
- [2] Shut-off valve, flow/return
- [3] Temperature control unit
- [4] High limit safety cut-out
- [5] Temperature capturing facility
- [6] Diaphragm safety valve 2.5 bar/3 bar or
- [7] Lifting spring safety valve  $\geq 2.5\text{ bar}$
- [8] Flash trap in systems  $> 300\text{ kW}$ ; not required if a high limit safety cut-out with shutdown temperature  $\leq 110^\circ\text{C}$  and a maximum pressure limiter are provided for each boiler instead.
- [9] Maximum pressure limiter
- [10] Pressure gauge
- [11] Low water safety cut-out. Alternatively one minimum pressure limiter or a replacement measure approved by the manufacturer for each boiler.
- [12] Non-return valve
- [13] Drain & fill valve (DFV)
- [14] Expansion line
- [15] Shut-off valve with lockout against unintentional closure (e.g. by sealed cap valve)
- [16] Drain upstream of the expansion vessel
- [17] Expansion vessel (to EN 13831)

- 1) Standard equipment level of the boiler control unit: The maximum achievable flow temperature in combination with Logamatic control units is approx.  $18\text{ K}$  lower than the shutdown temperature (high limit safety cut-out).

## 11.2 Safety equipment in accordance with the EC type inspection



The following pieces of equipment are components of the EC type inspection. We therefore recommend that you purchase safety equipment with the boiler.

The following safety equipment is included within the boiler's type-test qualification:

Safety component	Make	Component designation
Minimum pressure limiter as low water indicator	Sauter DSL 143 F001	TÜV ID ...6022
Water level limiter as low water indicator	Sasserath SYR 09333.20.011	TÜV.HWB. ...190
Maximum pressure limiter	Sauter DSH 143 F001	TÜV ID ...6023
Safety temperature limiter	Sauter RAK 13.5050 B	TÜV ID: 0000006982

Tab. 20 Approval designations of additional safety equipment in accordance with EN 12828:2003 for the floor standing condensing boilers Logano plus SB745

## 11.3 Requirements for alternative items of safety equipment and other pieces of equipment



If using different safety equipment to the type listed in Tab. 20, the following information must be observed so that the boiler's type-test qualification is not invalidated.

### 11.3.1 Safety valve requirements

- The safety valve must be suitable for discharging domestic hot water (e.g. via type-tested appliances with the TÜV.SV...D/G/H ID).
- The pipework between the boiler and the safety valve must be unrestricted. The pressure drop in the pipework between the boiler and the safety valve must be kept to a minimum.
- The safety valve must be able to safely discharge the rated output during a full load with the anticipated overpressure.
- The pressure drop of the discharge pipe must not exceed the nominal pressure of the safety valve by more than 10 %.
- The safety valve must be installed accessibly on the heat appliance or within close range in the flow pipe, without any barriers between the heat appliance and the safety valve.

### 11.3.2 High limit safety cut-out requirements

- Appliances which are suitable for responding must be installed (e.g. type-tested appliances with the TÜV.STB ID... or appliances according to EN 60730-2-9 (appliance type 2) or EN 14597).
- Observe the information in chapter 3.10 when adjusting the high limit safety cut-out.
- Limiters with a time delay are not to be installed.
- The limiter is generally installed with the temperature sensor set in the designated socket branch with a sensor pocket. The installation situation for other appliances is yet to be established. The sensor pocket is screwed in ex works.

### 11.3.3 Maximum pressure limiter requirements

- Appliances which are suitable for responding under increasing pressure must be installed (e.g. type-tested appliances with the TÜV.SDB...S... ID).
- Observe the information in chapter 3.12 of the installation instructions.
- Limiters with a time delay are not to be installed.
- The limiter sits on the boiler safety assembly (→ chapter 2.10). Possible connection with G½ ".

### 11.3.4 Minimum pressure limiter as low water indicator requirements

- Appliances which are suitable for responding under decreasing pressure must be installed (e.g. type-tested appliances with the TÜV.STB/F/... ID).
- Observe the information in chapter 5.6 of the installation instructions.
- The limiter sits on the boiler safety assembly (→ chapter 2.10). Possible connection with G½ ".

### 11.3.5 Water level limiter as low water indicator requirements

- Appliances which are suitable for responding with a lack of water must be installed (e.g. type-tested appliances with the TÜV.HWB... or TÜV.WB... ID).
- The low water indicator is installed on the boiler; possible connection G 2".

### 11.3.6 Burner requirements

- Gas burner certified in accordance with EN 676.
- Please observe EMC and Low Voltage Directives, and other relevant European guidelines.
- Please observe the instructions in chapter 2.2.

### 11.3.7 Boiler controller

- EMC and Low Voltage Directives must be observed.
- Please observe the instructions in chapter 3.10.

## Keyword index

### A

About the appliance .....	5
Appliance description .....	6
CE Declaration of Conformity .....	5
Correct use .....	5
Overview of possible fuels .....	5
Scope of supply .....	5
Accessories .....	5
Appliance description .....	6
Appliance details .....	
Operating conditions .....	5
Type plate .....	6
Assembly aids .....	6

### B

Boiler cover .....	24
Burner .....	22
Burner cable .....	26
Burner plate .....	22

### C

CE Declaration of Conformity .....	5
Check all connections for leaks .....	21
Checking and correcting the water pressure .....	33
Checking and correcting the water pressure in sealed unvented systems .....	33
Cleaning .....	31
Combustion air vents .....	12
Combustion chamber door .....	21
Commissioning .....	27
Commissioning the burner .....	28
Commissioning the control unit .....	28
Filling the heating system .....	27
Flushing the heating system .....	27
Preparing the heating system for operation .....	28
Commissioning report .....	29
Commissioning the burner .....	28
Commissioning the control unit .....	28
Connecting the boiler to the pipework .....	20
Connection on the flue gas and water sides .....	19
Control unit .....	24
Correct use .....	5

### D

De-commissioning .....	30
Details of appliance .....	
Dimensions .....	8
Dimensions .....	8
Disposal .....	36

### E

Electrical connection .....	25
Environmental protection .....	36

### F

Filling the boiler .....	21
Filling the heating system .....	27
Fitting .....	18
Check all connections for leaks .....	21
Connecting the boiler to the pipework .....	20
Filling the boiler .....	21
Fitting temperature sensors .....	26
Fitting the boiler front cover .....	24
Fitting the burner .....	22
Fitting the burner plate .....	22
Flue gas and water connections for heating system .....	19
Heating flow .....	20
Heating return .....	20
Installing the control unit .....	24
Levelling the boiler .....	19
Making the electrical connection .....	25
Recommended wall clearances .....	18
Routing the burner cable .....	26
Siting the boiler .....	18
Sound insulation mats .....	19
Fitting temperature sensors .....	26
Fitting the boiler front cover .....	24
Fitting the burner .....	22
Fitting the burner plate .....	22
Fitting the burner to the burner plate .....	23
Flue gas and water connections for heating system .....	19
Flue gas collector .....	31
Flue pipe sealing collar .....	20
Flushing the heating system .....	27
Fuels .....	5

### G

Guidelines .....	11
------------------	----

### H

Heating flow .....	20
Heating return .....	20

### I

Inspection .....	30
Inspection and maintenance .....	
Checking and correcting the water pressure in sealed unvented systems .....	33
General information .....	30
Inspection and service .....	30
Checking and correcting the water pressure .....	33
Cleaning heating surfaces and turbulators with a cleaning brush .....	31
Cleaning the boiler .....	31
Cleaning the flue gas collector .....	31
Fitting the cleaning cover .....	32
Preparing the boiler .....	30
Wet-cleaning the boiler .....	32
Inspection cover .....	32
Inspection report .....	34
Inspection reports .....	34
Installation .....	18
Fitting the burner to the burner plate .....	23
Installing the control unit .....	24

### L

Levelling .....	19
Levelling the boiler .....	19

## M

Maintenance report .....	34
Making the electrical connection .....	25
Minimum clearances .....	8
Minimum wall clearances .....	18

## N

Neutralisation .....	20
----------------------	----

## O

Obsolete equipment .....	36
Operating conditions .....	5
Overview of Logano plus SB745 .....	7

## P

Packaging .....	36
Preparing the heating system for operation .....	28
Prior to commissioning	
Converting the combustion chamber door .....	21
Opening the combustion chamber door .....	21
Product description .....	6

## R

Recommended wall clearances .....	18
Recycling .....	36
Regulations .....	11
Routing the burner cable .....	26

## S

Safety equipment .....	5
Safety pipe flow .....	20
Safety regulations .....	4
Scope of supply .....	5
Service .....	30
Service reports .....	34
Setting parameters .....	28
Shutdown	
Shutting down the heating system .....	30
Shutting down the heating system in emergencies .....	30
Shutting down the heating system .....	30
Shutting down the heating system in emergencies .....	30
Siting the boiler .....	18
Sound insulation mats .....	19
Standards .....	11
System examples .....	36

## T

Temperature sensor .....	26
Tools .....	6
Transport .....	15
Heavy duty rollers .....	17
Lifting with a crane .....	16
Moving the boiler with a forklift truck .....	15, 17
Moving the boiler with two pallet trucks .....	15, 17
Type overview .....	5
Type plate .....	6

## U

Unit data .....	9
Measurements .....	8
Output data .....	9

## W

Water pressure .....	33
----------------------	----

## **Buderus**

Cotswold Way, Warndon, Worcester WR4 9SW  
All Enquiries: 0844 892 3004

[www.buderus.co.uk](http://www.buderus.co.uk)

In the UK and IE, Buderus is a brand name  
of Bosch Thermotechnology Ltd.

# **Buderus**