




Control voltage 230 V~



Extra-low voltage



Note
Implement the installation, fuse protection, mains isolator, emergency stop switches and protective measures in accordance with local/national regulations.
Warning! Earth ye-gn must not be used as a control line.
Ensure phases are not interchanged.
Never use shockproof plugs.

1) The total current must not exceed 5A.